


Key	Function
ON/OFF	Setting the light permanent ON or OFF without motion mode
Sensor	Turn on Sensor mode
Hold time	The period of light keeping 100% brightness after moving objects leave the detection area.
Daylight threshold	Definition of the ambient brightness; only when the ambient brightness is lower than the preset specific lux amount, the sensor will work; when it's preset as "disable", the sensor will detects motion regardless the ambient brightness.
Sensitivity	In this area, movement will be detected and able to trigger the sensor. 100% detection area is also known as the strong sensitivity.
Remark	There is no Mosentek logo version for option

\* Remote Setting Tips: When press any button, if the light is flickering one time, means the setting is successful.



Size (L\*W\*H): 86\*40\*7mm

CR2025 battery

